# Roof Help



Name	: Roof.rb © Version 2		
Author	: TIG		
Description	: A set of Roof Making Tools.		
Menu Item	: Plugins > Roof > Sub-Menus see below		

# Hipped Roof:



#### Select a face.

Pick the tool on the menu.

Hipped Roof Settings		
Slope (Degrees OR A:B):	30	
Overall Eaves Fascia Height (mm):	200	
Overall Eaves Soffit Overhang (mm):	400	
Set Layer + Materials ? :	Yes	
Cancel	•	

In the resulting dialog enter the roof slope as an angle in degrees [e.g. 30], OR as a pitch A:B, [e.g. 2:5], then give the overall eaves height (+/-ve) & overhang (+ve only) [both zero = none], note that these are in 'current units' - shown here as 'mm'.

If additional settings are required (layer, materials etc) answer 'Yes' to the last question...

Roof Layer:	-ROOF
Roof Surface:	Roof Surface 💌
Roof Fascia:	Roof Fascia 💌
Roof Soffit:	Roof Soffit 🔹
0.	Cancel

In a second dialog suggested layer/material names are shown with <default>s and pre-existing layers/materials listed. If the layer or material ('Roof xxx') that is picked does not exist then it will

be made. You can pre-make or edit these later and they will be then used as you've set them. The default colours are: Roof Surface = mid-grey Roof Fascia = dark-grey Roof Soffit = light-grey

Within a session the chosen roof dialogs settings are remembered and reused.

A percentage complete progress appears in the bottom bar as the roof is calculated and made.

Simple faces roof very guickly, but complex ones will take several seconds to process, and because the processing is exponential very complex ones can take m u c h l o n g e r ! Faces with holes will only use the loop's outer edges as the eaves path.

Some faces - like crooked stars - can't form a single slope hipped roof. Sometimes the face/edge relationships get muddled in the model's database. Try re-making the original face: Delete it and redraw over one edge to try to remake it -

Or copy the face to one side, delete the original and move the copy back, these methods might now make the face 'roof'.

Some failed face shapes will 'roof' on a second attempt.

Some face shapes can never have a single pitch hipped roof applied to them - it is not geometrically possible - e.g. crooked stars.

Some very complex roofs might occasionally get made with a face [or faces] missing etc... but they will sometimes roof on a second attempt - inexplicably -try making a mirrored-copy [use Mirror.rb] of the problem face, then try roofing it and mirroring it and its roof back over the original works; or such problems are usually fixable by manually adding or drawing over some edges so that they face: if this happens please report the bug with details...

The new roof is a group.

Only equal pitched hipped/valleyed roofs are made, if you want to change these - e.g. make a hip into a gable - then you can use the SketchUp Tools to add edges, faces and move vertices etc....





## Mansard / Sprocket Roof:



See the general guidance for Hipped Roof above... This tool gives a roof with two pitches, with a crank at a given height above the eaves. The dialog differs from the Hipped Roof Tool in that two angles are entered for the lower and upper roof pitches and you also enter a height above the eaves level for the two pitches...

Mansard/Sprocket Roof Settings	
Lower Slope (Degrees OR A:B):	60
Upper Slope (Degrees OR A:B):	30
Height of Lower Roof (mm):	1200
Overall Eaves Fascia Height (mm):	200
Overall Eaves Soffit Overhang (mm):	400
Set Layer + Materials ? :	Yes
OK Cancel	R.

J The Material dialog is as shown in the Hipped Roof guidance above...

## Gable-Ended Roof:

Select the tool on the menu.

You now need to pick three points ...

Follow the prompts on the Bottom-Line and as Tool-tips at the cursor. Most types of inference are available.

It's recommended that you pick Ends, Intersections, Edges, Clines etc, otherwise picking freely on a Face or in space along an axis might give some unexpected roof sizes.

- Pick 1<sup>st</sup> Corner of the First Gable this also sets the Z-level.
- Pick 2<sup>nd</sup> Corner of the First Gable this determines the gable width in plan. Note this point need not be 'level' with the 1<sup>st</sup> corner, it will be transformed to an equal Z-level anyway.
- Pick a Point on the Line of the Second Gable. Note this point need not be 'level' with the other points, it will be transformed to an equal Z-level anyway: it also need not be perpendicular to the first two points as this is calculated anyway.

#### A dialog appears.

Gable Roof Settings	
Roof 'Slope' (in Degrees or A:B or ^Height(mm)):	30
Overall Eaves Fascia Height (mm):	200
Overall Eaves Soffit Overhang (mm):	400
First Gable Overhang (mm):	400
Second Gable Overhang (mm):	400
First Gable Type:	Verge from Fascia 💌
Second Gable Type:	Verge from Fascia
Set Layer and Materials ? :	Yes 💌
OK Cancel	₩

In this dialog enter the details: firstly the roof slope - as an angle in degrees [e.g. 30] OR as a pitch A:B [e.g. 2:5], OR alternatively as a height above the fascia [e.g. ^1234.5]. Note how it must be pre-fixed with a ^ (caret/circumflex symbol) and how it must be in your current units (sorry decimal feet/inches only - 1.5 NOT 1'6"). Then enter the overall eaves fascia height & soffit overhangs (both +ve only) [zero=none] and then the overhangs for the first and second gables [zero=none], and 'gable-type' for the first and second gables from the pull-downs [see below for details\*]. For additional settings (layer, materials etc) say 'Yes' to the last question ...

Roof Layer:	-ROOF
Roof Surface:	Roof Surface
Roof Fascia:	Roof Fascia
Roof Soffit:	Roof Soffit
First Roof Gable:	<default></default>
Second Roof Gable	: <default></default>

In a second dialog suggested layer/material names are shown with the layers/materials listed. If the layer or material ('Roof xxx') that is picked does not exist then it will be made. . You can pre-make

or edit these later and they will be then used as you've set them. The default colours are:

Roof Surface = mid-grey Roof Fascia = dark-grey Roof Soffit = light-grey Roof Gable 1 = white Roof Gable 2 = white

\*The gable-types on the pull-down options (each available for either gable) are:



'Blank' - this gives a blank gable that can be useful later:

for example when used in combination with a zero overhang, if you want later to edit the roof and move its gable apex over onto a second roof's slope to make a valley - or for example it's useful if you want to put dormers with a steeper pitch into a larger roof etc. To do this edit the group and manually delete the gable face, then move the gable's apex (constrained to apex ridge's vector), exit the group edit; now edit the second roof group, select all and intersect with the gable-group to form valley lines etc, if necessary briefly exit the group edit and hide the gable-group, go back to editing the second roof group and delete unwanted faces and edges which will be inside the whole, exit the edit: select the gable-roof group and the second roof group and the second roof second roof group and explode them, immediately group them back together as one you should now have a valley where the two roofs are combined.

'Blank with Fascia' - as above BUT adds a fascia below the blank gable end... As above this option is useful for later editing - e.g. for making a gable into a hip - give the gable desired the Roof Surface material (or use the material browser and eyedropper later) - when you edit the group you have a vertical piece of roof that you can manually change to a hipped face by moving its apex vertex. To get an exact angle draw a construction (guide) line with the protractor on the side fascia and then select and move it to the gable/fascia's mid-point. When you relocate the apex snap it to the intersection of the ridge and this temp guide line.



'Verge from Fascia' - this uses the eaves-fascia depth to make the verge (barge-board), its material [if any] will match the fascia. 'Verge from Soffit' - this uses the eaves-soffit overhang to make the verge (barge-board), its material [if any] will match the fascia.



'Verge by Height' - this defaults to the eaves-fascia depth (or if this is 0 to 100mm/4") to make the verge (barge-board), you must enter a new value > 0 and < 'height of roof apex above fascia', its material [if any] will match the fascia. 'Verge by Width' - this is measured perpendicular to the roof slope, this defaults to the eaves-fascia depth (or if this is 0 to 100mm/4") to make the verge (barge-board), you must enter a new value > 0 and < 'height of roof apex above fascia', its material [if any] will match the fascia.



'Verge by Height, with Fascia' - As 'Verge by Height' above but also makes a fascia along the bottom edge, its material [if any] will match the fascia. 'Verge by Width, with Fascia' - As 'Verge by Width' above but also makes a fascia along the bottom edge, its material [if any] will match the fascia.



'Verge with Fascia [All Equal]' - As 'Verge by Width, with Fascia' above but also makes a fascia along the bottom edge with the same dimension (no dialog), its material [if any] will match the fascia. 'Lids': with Roof Materials set there's a closing dialog as above: answer 'Yes' to make the Lid(s) grey as shown left; or 'No' to match the soffit (white) as shown right.



'Verge by Height, with Box-Eaves' - As 'Verge by Height' above, but also makes a boxed fascia using the fascia and soffit sizes along the bottom edge, its material [if any] will match the fascia. 'Verge by Width, with Box-Eaves' - As 'Verge by Width' above, but also makes a boxed fascia using the fascia and soffit sizes along the bottom edge, its material [if any] will match the fascia. Note: some options aren't available with some permutations and you will get warning dialogs and newly reset main dialogs reopening - e.g. set the fascia depth to 0 and you then can't use any of the verge options 'from fascia' etc...

## Pyramid Roof:

These two pyramid roofs below are the same footprint - one with a 30 degree slope short-edge and the other set on the long-edge chosen...



#### Select the tool on the menu.

You now need to pick three points ...

Follow the prompts on the Bottom-Line and as Tool-tips at the cursor. Most types of inference are available.

It's recommended that you pick Ends, Intersections, Edges, Clines etc, otherwise picking freely on a Face or in space along an axis might give some unexpected roof sizes.

- Pick 1<sup>st</sup> Corner of the Pitch-Side this also sets the Z-level.
- Pick 2<sup>nd</sup> Corner of the Pitch-Side this determines the edge from which the slope is set. Note this point need not be 'level' with the 1<sup>st</sup> corner, it will be transformed to an equal Z-level anyway.
- Pick a Point on the Line of the Other Side. Note this point need not be 'level' with the other points, it will be transformed to an equal Z-level anyway: it also need not be perpendicular to the first two points as this is calculated anyway.

#### A dialog appears.

Pyramid Roof Settings	×	
Roof 'Slope' (in Degrees or A:B or ^Height(mm)):	30	
Overall Eaves Fascia Height (mm):	200	
Overall Eaves Soffit Overhang (mm):	400	
Set Layer and Materials ? :	Yes	
OK Cancel	N	

In this dialog enter the details: firstly the roof slope - as an angle in degrees [e.g. 30] OR as a pitch A:B [e.g. 2:5], OR alternatively as a height above the

fascia [e.g. ^1234.5]. Note how it must be pre-fixed with a ^ (caret/circumflex symbol) and how it must be in your current units (sorry decimal feet/inches only - 1.5 NOT 1'6").

For additional settings (layer, materials etc) say 'Yes' to the last option. See the Hipped Roof Material guidance above...

A pyramid roof is made to the specified parameters. It differs from the hipped roof version - since you can select the overall height (like with a gable roof) and if it is given a slope/pitch it is applied to the face abutting the edge specified by the first two points you picked, and the other perpendicular faces will have different angled slopes to suit; there is no ridge to a pyramid, only an apex.

## Get Slope:

Select a sloping face and this tool opens a dialog that gives you the Face's Angle in degrees and as a Slope (Pitch) in A:B format.

-level anyway. Jlar to the first two points as this is calculated anyway.



# Help:

Opens this file...